

Introduction to Remote Sensing

Physical principles: Image characteristics and surface properties

Patrick Hostert

patrick.hostert@geo.hu-berlin.de

<http://www.hu-geomatics.de>


Tel.: (030) 2093 – 6905

RUD 16, 2'226



Recapitulation from last week

- (1) Name 3 phenomena that illustrate the different resolutions in Google Earth. Which factors drive these phenomena?
- (2) Why can we not assume that there will ever be the „ideal remote sensing device“ in respect to all the different resolutions?
- (3) Which size (in MB) will the following dataset have:
 - 5,000 x 7,000 pixels
 - 16-bit radiometric resolution
 - 9 spectral bands




Content

- Wavelengths and spectral properties
- Spectral surface characteristics
- Imaging spectrometers
- Spectral measurements: Demo ASD


The spectral dimension of remote sensing data



True color image of the stadium on the Wisconsin-Madison university campus, US (Lillesand, Kiefer and Chipman, 2008)



False color infrared image of the stadium on the Wisconsin-Madison university campus, US (Lillesand, Kiefer and Chipman, 2008)




(Lillesand, Kiefer and Chipman, 2008)

- How do we produce such measurements that allow differentiating different surfaces or monitoring changes of surfaces over time?

Basics – what is electromagnetic radiance, what do we measure?


The nature of electromagnetic energy



- Energy (or light) travels as a periodic electromagnetic field (sinusoidal wave)
- Light travels with – surprise! – **speed of light (c)**
- Relevant characteristics are **wavelength λ [nm]** and **frequency ν [Hz]**
- The wavelength is hence defined according to: $\lambda = c / \nu$

Basics – what is electromagnetic radiance, what do we measure?

The nature of electromagnetic energy




- In remote sensing, wavelength is the common unit
 - 1 nm (Nanometer) = 1×10^{-9} m
 - 1 μ m (Mikrometer) = 1×10^{-6} m
 - 1 mm (Millimeter) = 1×10^{-3} m
- In remote sensing, a target's spectral properties are measured across a wavelength region and in several or even many distinct bands

Basics – what is electromagnetic radiance, what do we measure?

Electromagnetic spectrum

- Spectrometers are sensitive to wavelengths beyond the human eye's sensitivity
- optical remote sensing makes use of the visible light ($\sim 400\text{-}700\text{ nm}$), and the near and short-wave infrared ($0,7\text{-}\sim 3\text{ }\mu\text{m}$)
- thermal remote sensing detects thermal infrared radiation ($5\text{-}15\text{ }\mu\text{m}$)
- radar remote sensing detects microwave radiation ($1\text{ mm-}1\text{ m}$)



<http://www.arm.gov/news/facility/post/5946>

Abbreviations:

VIS = visible: $400\text{-}700\text{ nm}$

nIR = near infrared: $0.7\text{-}1.3\text{ }\mu\text{m}$


SWIR = short wave infrared: $1.3\text{-}3\text{ }\mu\text{m}$

tIR = thermal infrared: $5\text{-}15\text{ }\mu\text{m}$

Basics – what is electromagnetic radiance, what do we measure?

Measuring surface properties

- Geo- and environmental sciences are primarily interested in processes at the Earth's surface
- From the interaction between radiation and surface we can draw conclusions on the surface's characteristics
- Each surface's interaction with radiation depends on its physical and chemical properties and varies with wavelength
- That's the **basis for the entire remote sensing process**




- to start with: let's control illumination and ignore the atmosphere
- Let's assume laboratory conditions (using an artificial light source instead of the sun)

Basics – what is electromagnetic radiance, what do we measure?

A laboratory setup

- Lab measurements are performed with a spectrometer and allow an exact characterization of a surface
- We control illumination by using a lamp
- We control the distance and angle to the surface to be measured (usually nadir measurement)
- We control the instrument calibration, i.e. we measure and eliminate the noise from the signal



Typical laboratory setup with an ASD spectrometer (in blue), the fiber optics ending in a pistol grip mounted on a tripod and a video spot as artificial illumination source. The bright target on the smaller tripod is a calibration panel.

<http://www.lineas.cchs.csic.es/biospec/methods/laboratory>

Basics – what is electromagnetic radiance, what do we measure?

Measuring target radiance


- In Earth remote sensing, we perform measurements from above, i.e. we are interested in the reflected portion of the energy
- At any surface, incoming radiation is either partially or fully:

- reflected (ρ)
- absorbed (α)
- transmitted (τ)

- The sum of all three terms is always 100% of the incoming radiance:

$$\rho + \alpha + \tau = 1$$

(Law of conservation of energy)




<http://www.edaphic.com.au/emittance-absorbance-reflectance-transmittance/>

- the physical quantity measured by the sensor is **radiance**
- The unit of radiance is watts per square meter per steradian: $\text{W} \cdot \text{m}^{-2} \cdot \text{sr}^{-1}$

Basics – what is electromagnetic radiance, what do we measure?

Excursus – solid angle

- A three-dimensional angle is called **solid angle Ω** :
- Definition Ω : the area A cut out from a sphere with the radius r
- unit: **steradian [sr]**
- $\Omega = 1$ sr if a conus cuts an area A of 1 m^2 from a sphere with the radius $r=1\text{m}$




<https://de.wikipedia.org/wiki/Raumwinkel>

Basics – what is electromagnetic radiance, what do we measure?

From radiance to reflectance


- The problem with radiance as the unit of measure: it varies with illumination
- Needed: a stable measurement over time, independent of illumination, to avoid introducing changes when measuring unchanged surfaces



- Solution: normalize the measurement relative to the irradiation
- The ratio between radiance reflected at the Earth's surface and the incoming radiation is called **reflectance**
- $\text{Reflectance} = \text{Rad}_{\text{reflected}} / \text{Rad}_{\text{incoming}}$
- reflectance is the percentage of the total measurable radiation, which has not been absorbed or transmitted

Basics – what is electromagnetic radiance, what do we measure?

Diffuse und direct reflectance




- The observation direction influences the measured signal
- In most cases, surfaces reflect the incoming radiation diffusely
- A special case is **Lambert reflectance** that is often assumed in remote sensing for the sake of simplicity
- Lambert reflectance: the measured signal is independent of the observation direction (no directionality effects in the reflected signal)
- In reality, most surfaces reflect in a mixed way, which can be described by the so called **Bidirectional Reflectance Distribution Function (BRDF)**
- Spectral reference panels (e.g. Spectralon®) are almost Lambert reflectors

Spectral surface characteristics

Reflectance Spectra

Introduction


- Example of a vegetation measurement (green) in the field



Reflectance Spectra

White Reference



- In addition to the target surface, a white surface is measured
- This so-called **White Reference** is a surface with a reflectance of almost 100% across the entire wavelength spectrum
- Spectralon®, alternatively BaSO₄
- Reference panels allow measuring the maximum backscatter for a particular point in time and position on Earth
- If a panel reflects 100% across the spectral region of interest, its radiance is the same as the incoming radiance, i.e. it can serve for normalizing to reflectance



Reflectance Spectra

Reflectance

- The ratio between the target radiance measured and the reference panel (white reference) is hence **reflectance**
- **reflectance** = Rad_{target} / Rad_{WR}
- reflectance is the percentage of the total measurable radiation, which has not been absorbed (or transmitted)
- Note: The division by Rad_{WR} can result in considerable noise in wavelength regions with poor signal-to-noise-ratio



Reflectance of Different Surfaces and Materials

Introduction



<http://oceanoptics.com/application/agricultural-measurements-monitoring/>



<https://nau.edu/lci/isl/>



http://gallery.usgs.gov/photos/08_11_2010_a1Uh83Jww6_08_11_2010_1#.VipK0n41-Ht


Reflectance of Different Surfaces and Materials

Introduction

- The object-specific influence determines object-specific patterns in the spectrum of recorded electromagnetic radiation
- The change of irradiation at the Earth's surface results from material-specific absorption
- We distinguish between absorption features due to electron transitions, molecular vibrations und molecular rotation
- Electron transitions require a high amount of energy
→ they occur mostly in the VIS
- Vibration and rotation can lead to narrow absorption bands also in the nIR and SWIR

Reflectance of photosynthetic active vegetation

- Vegetation produces a distinct spectral reflectance pattern due to its leaf and cell structure, its physiognomy, and complex stand structure
- The reflectance of photosynthetically active vegetation is characterized by different factors in the VIS, nIR and SWIR:
 - VIS – leaf pigments
 - nIR – cell structure
 - SWIR – water content
- Photosynthetically inactive plant parts differ considerably from active ones across different wavelength regions




Reflectance of photosynthetic active vegetation

Single leaf reflectance

- The reflectance of a single leaf or needle is determined by various absorption, transmission and reflectance characteristics


Important characteristics are:

- The local reflectance maximum in the VIS (green peak) is small
- The high reflectance in the nIR results in the so-called "red edge"
- Thus, transmission in the nIR is very high, in the VIS very small
- Lignin and cellulose, and particularly water, lead to high absorption, especially in the SWIR



Reflectance of vegetation – plant stress


- Accordingly to the factors determining reflectance, there are also three determining damaging factors
 - Pigments
 - Cell structure
 - Cell water
- Destruction of chlorophyll causes a flattening of the C_{ab} -specific absorption bands
- Destruction of the cell structure causes a shift of the red edge towards the nIR and a flattening of the nIR-plateau
- Both effects can be detected with remote sensing systems



(Gausman 1974)

Reflectance of vegetation – water stress


- Dehydration of the cell leads to a flattening of absorption bands that depend on water content
- Additionally, albedo increases considerably
- Absorption bands of cellulose and lignin appear more clearly
- Heavy water stress ultimately leads to a destruction of the cell structure and a decrease in plant metabolism



Reflectance of vegetation

Multi-layered leaf reflectance

- The plant's leaf organs produce complex reflectance patterns
- In the VIS, one leaf layer is enough to absorb almost the entire radiation
- In the nIR, complex radiation paths relate to multiple transmission



Reflectance of vegetation


Multi-layered leaf reflectance

- As the degree of transmission varies greatly in different wavelength regions, non-linear changes of the reflectance behaviour occur with an increasing number of leaf layers
- A saturation of the reflectance in the nIR is – depending on the character of the respective leaves or needles – reached with 6 to 7 leaf layers
- A commonly used measure for the number of leaf layers is the so called “leaf area index” (LAI), measured in $[m^2 \cdot m^{-2}]$

Reflectance of vegetation

Plants as a system

- plants do include photosynthetically inactive parts
- fruits, spines, flowers, bark, and dead parts of the plant affect the reflectance
- Also structural factors affect the signal
- Aircraft or satellite based methods detect an integral signal
- In remote sensing, the analysis often focuses on the green parts of the plants only




Reflectance of soils

Soil moisture

Example: silty loam

Alteration of

- Form of the reflectance curve
- Albedo
- Absorption depth
- FWHM (here: maximum absorption depth, similar to sensitivity function of sensors -> compare slides on spectral resolution)




Reflectance of soils

Organic material content

- Figure shows difference between low and very high organic content


With increasing portion of C_{org}

- the total reflectance decreases
- particularly the reflectance at $0.6 \mu\text{m}$ decreases
- the depth of the water-dependent absorption bands decreases



Reflectance of water

- Water, in its fluid phase, is an excellent absorber (especially in the infrared)



- Clear water reflects less than 5% in the VIS
- In the nIR and SWIR, reflectance is close to 0
- Accordingly, water is almost a black body in these wavelength regions
- In its frozen form of ice, and particularly as snow, water is a good reflector

Imaging spectrometers

Imaging spectrometers

- Field / lab spectrometers measure a point on Earth on the ground, ideally similar to measuring a single pixel from an airborne or satellite platform
- Imaging spectrometers allow measuring continuous images in 100s of bands (also referred to as “hyperspectral remote sensing”)






Image subset (left) and reflectance spectra from airborne HyMap image over Berlin (right). Colored circles in the close-up on the „Lustgarten“ correspond with colors of spectra. Gaps in spectra around ca. 1,400 nm and 1,900 nm result from atmospheric water vapor absorption.


Imaging spectrometers

- NASA/JPL Airborne Visible/Infrared Imaging Spectrometer (AVIRIS) continuously improved since the late 1980s
- Measures 224 bands from 400 to 2,500 nm
- Each pixel is a spectroscopic measurement from an airborne platform that needs thorough calibration and atmospheric correction to become a reflectance spectrum

EACH SPATIAL ELEMENT HAS A CONTINUOUS SPECTRUM THAT IS USED TO ANALYZE THE SURFACE AND ATMOSPHERE




<http://aviris.jpl.nasa.gov/aviris/concept.html>



- As of today, there is no operational imaging spectrometer on a satellite platform
- Reason: spectrometers need fine spectral resolution and sampling interval -> low irradiance input compared to broadband instruments -> poor signal-to-noise-ratio -> signal retrieval from space not trivial (IFOV, atmospheric influence)

Imaging spectrometers

Applications



- Next slides from 2 presentations by Guanter et al.:
 - Overview of the Science Perspectives of EnMAP. ISRSE Berlin 2015
 - Overview of the EnMAP Imaging Spectroscopy Mission, IGARSS Milan 2015

World Trade Center area, New York

U.S. Geological Survey
Clark et al., 2006
NASA/JPL AVIRIS data
Sept 16, 2001 16:21 GMT

USGS
Imaging Spectroscopy
Tetracorder 4.0awtc2
product

Spectral Shape Map


This map shows materials whose spectra are similar to the reference materials below. It is not a map of the identification of these materials. A similarity map is analogous to a map of materials with similar colors viewed with your eyes. The colors may indicate similar compositions.

- concrete (WTC01-37B)
- concrete (WTC01-37Am)
- cement (WTC01-37A)
- dust (WTC01-15)
- dust (WTC01-28)
- dust (WTC01-36)
- gypsum wall board

Image sampling:
1.7 meters/pixel


N
↑
200
meters

<http://speclab.cr.usgs.gov/wtc/>




❖ The not-so-happy story of spaceborne imaging spectroscopy for Earth observation:

- Current missions → So-called “technology demonstrators”
 - Low data quality and limited acquisition capability
 - Examples: EO-1 Hyperion (USA NASA, 2000) & CHRIS/PROBA (UK/ESA, 2001), designed for a 1-year lifetime!
 - There are more imaging spectrometers for planetary observation than for Earth observation!
 - Most of imaging spectroscopy applications rely on airborne spectrometers → heritage from AVIRIS (NASA-JPL, since 1987)
- **EnMAP (launch 2018) expected to fill this gap in operational spaceborne imaging spectroscopy**




EnMAP – Main Mission Parameters




- ❖ Push-broom imaging spectrometer
- ❖ Sun-synchronous orbit, 11h LTDN
- ❖ Spectral range
 - VNIR: 420 nm to 1000 nm
 - SWIR: 900 nm to 2450 nm
- ❖ Spectral sampling distance
 - VNIR ~6.5 nm
 - SWIR ~10 nm
- ❖ Data acquisition
 - 1000 km/orbit
 - 5000 km/day
- ❖ Swath width 30 km
- ❖ Ground sampling distance 30 m
- ❖ Revisit time
 - 27 d nadir
 - 4 d with 30° across-track pointing
- ❖ Mission lifetime ≥ 5 years

Key mission characteristics for scientific use of EnMAP



- Up to 4 days revisit time with tilted obs.
- Ground segment distributing geometrically-corrected reflectance data
- Co-existence with Sentinel-2 & Landsat-8
- Open data policy




→ **High-performance imaging spectroscopy system for Earth observation**

Imaging Spectroscopy & Science

→ Quantitative mapping for a wide range of research fields

→ Great potential for new (and unexpected!) applications



EnMAP Science Plan

Content


- Research context and significance
- General mission framework
- EnMAP perspectives and impact
- Scientific exploitation strategy

www.enmap.org

Science Plan

of the *Environmental Mapping and Analysis Program (EnMAP)*

October, 2012



GFZ Potsdam



Luis
Guanter



Hermann
Kaufmann



Karl
Segl



Saskia
Förster



Christian
Rogass



Theres
Küster



Sabine
Chabrillat



André
Hollstein

Scientific leadership + Soils and Geology

LMU München



Wolfram
Mauser



Tobias
Hank



Matthias
Locherer

Agriculture

Uni Trier



Joachim
Hill



Henning
Buddenbaum

Forests

DLR Oberpfaffenhofen



Andreas
Müller



Tobias
Storch



Uta
Heiden

Ground segment + Urban

HU Berlin



Patrick
Hostert



Pedro
Leitão



Sebastian
v. d. Linden



Andreas
Rabe

Natural Ecosystems and Ecosystem Transitions

HZG Geesthacht



Hajo
Krasemann



Roland
Doerffer



Hong
Yan Xi

Coastal and inland waters

ESA Uni Lethbridge



Mike
Rast



Karl
Staenz

Scientific advisory

DLR Bonn

Christian Chlebek

Godela Roßner


Stefanie Schrader

Sebastian Fischer



Christoph Straif

- Software for the scientific exploitation of EnMAP data
- Also contains pre-processing tools for EnMAP data
- Free, open source and platform independent
- Reference algorithms for different application fields being developed by EnSAG partners




Download from
www.enmap.org/?q=enmapbox



van der Linden, S., Rabe, A., Held, M., Jakimow, B., Leitão, P., Okujeni, A., Schwieder, M., Suess, S., & Hostert, P. (2015). The EnMAP-Box—A Toolbox and Application Programming Interface for EnMAP Data Processing. *Remote Sensing*, 7, 11249



Summary



Recapitulation for next week

- (1) Read chapters 2.1.2 and 2.1.3 in „Albertz (2007): Einführung in die Fernerkundung. Wiss. Buchges., Darmstadt.“ The pdf is provided in Moodle. 2.1.2 is preparatory for next week, 2.1.3 is a summary of today's lecture.
- (2) Name the most important influence factors of the atmosphere on the signal that we measure with satellite or airborne sensors.

Outlook


Next week we will focus on:

From Sun to Earth – and back into space

Thanks for your attention!

Excursus: Lab and field spectrometers

- Spectrometers: large number of detectors
- ASD Fieldspec: 512 detectors within the range of 350-1,000 nm
- 750 bands sequentially sampled with one detector in the range of 1,000-2,500 nm
- sensitivity of individual detectors can be displayed as a function of a Gaussian distribution
- shape of the distribution determines resolution of each wavelength range




<http://www.asdi.com/mining-ore-properties/faq/what-is-spectral-resolution>



- The **spectral resolution** is the width of the sensitivity function at half maximum height (FWHM – Full Width at Half Maximum)



Excursus: Lab and field spectrometers

- The sensitivity functions of single detectors cover different wavelength intervals
- The ***spectral sampling interval*** is the number of wavelengths between the wavelength of maximum sensitivity of two neighbouring detectors



<http://www.asdi.com/mining-ore-properties/faq/what-is-spectral-resolution>


Excursus: Lab spectroscopy



- Data in Google Earth™ show that many factors affect remote sensing data
- In order to explain interactions of irradiation and a particular surface, we eliminate disturbing factors under lab conditions
- **Laboratory conditions:** constant measurement geometry (angles & distances), nadir view (no displacement), no atmosphere, reduction to a point measurement


Excursus: Lab spectroscopy

- - **Lamp (1)** as an energy source with constant radiation
 - Calibrated **spectrometer (2)**
 - **Sensor (3)**
 - **Target (4)**
 - **White reference (WR) (5)** for calibration (adjustment to illumination conditions), by measuring the incoming radiance
-
- → The spectrometer allows radiance measurements as well as reflectance measurements
 - **Reflectance** = $\text{Rad}_{\text{Target}} / \text{Rad}_{\text{WR}}$



Excursus: Lab measurement setup

- Angular aperture of the spectrometer: 25°
- Measurement height: ~ 0.5 m
- Aperture radius : 0.108 m
- Area: $0.0368 \text{ m}^2 = 368 \text{ cm}^2$
- Calculation of area depends on measurement height



- The solid angle of our ASD Lab/Field Spectrometer is 0.149 sr, i.e. it measures 0.149 of a half sphere of 2π ($\sim 2.4\%$)